



Part numbers on following page.

IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



**Stocked  
at Depot**

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
1	Damper Blade Assembly		22890	
2	Starter Section Assembly		22069B	Y
3	Top Standoffs	Qty. 4 req.	11864i	
4	Smoke Shield	Qty. 2 req.	20399	
5	Refractory - Back	Qty. 2 req.	13319	
6	Refractory - Side	Qty. 4 req.	13320A	
7	Firescreen Assembly	Qty. 4 req.	12267	Y
8	Door Support	Qty. 2 req.	4012-108	
9	Refractory - Hearth		13321B	
10	Ashlip	Qty. 2 req.	20401	
11	Damper Control		20549	
12	Grate		GR12	Y
13	Outside Air Kit		AK17	
14	Outside Air Plate Assembly		19081A	
15	Long Cable Tie	Qty. 2 req.	19954	
16	Outside Air Shield		33271	
	AK17 Installation Instructions		31168	
	Air Kit Fastener Pack		13580	
	Damper Rod		28900	
	Damper Weight		19785A	
	Door Track (Lower)	Qty. 2 req.	4012-002	
	Door Track (Upper)	Qty. 2 req.	15425	
	Firescreen Handle		4021-150	
	Firescreen Rod	Qty. 4 req.	11866B	Y
	Gas Access Panel (for use with Air Kit)	Qty. 2 req.	31636	
	Nailing Flange	Qty. 8 req.	31190	
	Refractory Bracket	Qty. 4 req.	13328	
	Refractory Retainer	Qty. 2 req.	11847	
	Refractory Standoff	Qty. 2 req.	13327D	
	Smoke Deflector	Qty. 2 req.	20603B	
	Strip Protector	Qty. 4 req.	18320	
	Installation Instructions & Owner's Manual		20396	